



3-4/02/2018

Date: 22.01.2018

Time: 16.00

Communication# 07

Document: 07

From: The Organising Committee
To: All Competitors
Cc: The Stewards of the Meeting
The Clerk of the Course
The Secretary of the Meeting

Classic

X

Legend

X

Challenger

X

Demo

X

LEGEND BOUCLES® – POSITIONNING INSTALLATION NOTICE

Composition of the kit :

The will be delivered to you in a bag containing:

- 1 GPS box
- 1 USB / Mini USB Cable (if charging is required during the rally)



GPSDevice + USB wire

INSTALLATION OF THE EQUIPMENT IN THE VEHICLE

1. GPS Connection

There is no connection needed in the car. No power and no external antennas !



2. Installing of the GPS box

It must be installed within reach of the driver and co-driver with adhesive Velcro only, on a smooth surface, on the dashboard or on the roll bar. The 2 small LEDs **must be and remain visible**. Validation of the location and correct operation of the VDS Racing box will be done by a VDS Racing technician. **The box has an emergency call button in case of an emergency request.**



- > *Do not use rislans or tape to fix the box, only Velcro adhesive*
- > *Any wrong triggering of the emergency button (especially by incorrect fixing of the box) may be sanctioned by the race director.*

GPS Kit operation

The box remains permanently operational.

Meanings of the different status of the LED on the top of the box :

- **Orange LED: powered box, charging**
- **Green LED: if flashing, searching for GPS. If fixed, GPS OK**
- **Yellow LED: if flashing, searching for GSM/GPRS, if fixed GSM/GPRS OK**

Whatever the color, if the LED is flashing, the function is searching. If it is fixed, the function is OK. Meaning of the LED on the box side : red flashing confirms the emergency call is taken into account. The location and operation of the ensemble will be validated by a VDS Racing technician. Therefore, it will be forbidden to disconnect the power supply to the GPS box.

A lithium battery internal to the case will allow electrical continuity in case of accidental power failure 12V.

*Contact : 07 68 88 25 57 ou 06 95 64 61 76
ballet@vdsracing.com - www.vdsracing.com*